Stunt Scooter



WARNING:

- Make sure you read and follow all the warnings and instructions written in this manual before using the scooter
- You might risk serious injury from collisions, falls or loss of control if you fail to read, follow or understand all the basic operational instructions and warnings stated in this manual
- It is your duty to check as well as obey all the laws and regulations, in your region
- It is advice to keep your fingers and toes away from all the moving parts of the scooter
- Do not touch the braking mechanism after braking, as it will get hot from continuous use
- · Use common sense and good judgement to avoid any accident or injury

IMPORTANT NOTE:

- Avoid riding the scooter at night or during poor visibility
- It should always be ridden by only one person, in all cases
- Obey all traffic and pedestrian laws and regulations
- Be very careful when riding on wet pavements due to reduced wheels traction and braking action
- Please check and tighten all the self locking nuts and fixings, periodically, as these may lose their effectiveness due to prolonged use
- · Follow the outlined instruction for scooter assembly, and avoid modifying the scooter

SAFETY ADVICE:

- The product is for children above 8 years
- Maximum load: 100 kgs
- It is not meant for extreme sports
- It is advised to inspect and maintain the scooter appropriately prior to use
- Always wear protective equipment, which includes helmet and protective pads, to reduce the risk of injury
- Keep away from road or where there is incoming traffic
- To be used on clear, dry and flat surface
- It is advised to periodically add oil for lubrication
- Replace bearings when worn
- Please keep your feet on the scooter's plate and never ride with one hand
- Do not ride it on slippery surfaces
- Avoid riding the scooter on stairs, as the scooter might overturn causing serious injuries

DAILY CARE:

- Do not keep the scooter under direct sunlight or in wet places for a very long time. This may damage a few parts
- Clean the scooter, from time to time, and keep it dry
- · You may use a damp cloth and a mild detergent for cleaning it


A GUIDE TO SAFE SCOOTERING:

- This scooter, under no circumstances, should be ridden on a public highway or busy road
- Do not ride it under the influence of alcohol
- Avoid uneven pavements or potholes, as this may cause you to lose control of the scooter
- Do not ride it under bad weather conditions, like strong wind, heavy rain or snow
- Please get off the scooter or slow down if the road condition is poor
- The product is limited for on adult use, only
- Always keep your eye on the pavement and avoid wearing anything that may obstruct your visibility
- Do not ride the scooter in the dark or when the weather conditions bad
- Don't carry anything in your hand while riding the scooter
- In all cases, place both hands on the handlebar to ensure complete control on the scooter
- Avoid using earphones/headphones, as this may restrict your hearing
- If riding under poor light, it is recommended you wear light reflective clothing
- It is highly recommended to wear safety equipment before riding the scooter
- Wear shoes to avoid injuring your feet
- Don't wear loose clothing or scarves or anything that hangs, as this may get caught in the wheels
- · When riding near parked vehicles, watch for car doors being opened

A GUIDE TO CHILDREN'S SAFETY:

- Never leave your child unsupervised while s(he) is riding the scooter
- Always check for any loose screws, nuts and bolts before letting your child ride the scooter
- Make sure your child is capable of riding this scooter
- Make your child wear all the safety equipment's to avoid injuries, which includes helmet, gloves, knee
 pads, elbow pads and wrist guards
- Never let your child ride a scooter on the road
- When riding the scooter on the pavement, make sure your child gives pedestrians right-of-way and doesn't ride too close to them

CONTENTS



ASSEMBLY:


- Slide the handlebar stem over the threaded locking section
- Ensure the arrow on the fork is facing forward and the handlebars sweep backwards
- Tighten the bolts evenly and tightly using the Allen key provided
- Make sure the wheels face forward when the handlebars
- are held facing straight

NOTE:

• A bolt that seems fully tightened may require further turning after tightening the other two bolts


ASSEMBLED:

- Please check all screws and fittings are secure before giving to a child
- Ensure there are no broken components
- Ensure all locking devices are engaged
- The items shall be used with caution, since it requires great skill, so as to avoid falls or collisions causing injury to the user and third parties



Certification

EN14619:2005



USE:

- Hold both handgrips firmly
- Put one foot towards the front of the deck
- With other foot, push off the ground to propel the scooter forward
- Both feet can fit on the deck when desired speed has been reached
- To stop, step on the brake with the rear foot.